Sky Arrow 650 Equipment & Options						
Notes	Description AIRFRAME & CONTRO	VLA & FAR23-TCS MA005	vla & far 23-tcns MA006	vla & FAR23-TCNS RAW MA007		
	Weather-resistant white finish	√v	٧	٧		
	Tinted canopy with air Vents, Sliding Side Window & Lock	٧	√	√		
	Tinted removable aft windows	√	√	√		
	Non-skid floor w/ Map/Glove compartment box	√	√	√		
	Adjustable front rudder pedals	√	√	√		
	Seat cushions	√	√	√		
	Cabin heating, ventilation & canopy demisting system	√	√	√		
	Seat belts & shoulder harness, five points, dual	٧	√	√		
	Canopy release system	V	V	V		
	Baggage containers (behind & under the rear seat)	V	V	V		
	Map box under front seat	V	V	V		
	First aid kit	٧	V	V		
	Engine firewall	٧	٧	V		
	Fire extinguisher	٧	٧	٧		
	Fuel tank 68 lt	V	٧	V		
	Electric pitch trim Electrical interface for RAWAS devices	V	V	V st		
	Electrical Interface for RAWAS devices Mechanical interfaces for RAWAS devices	-	_ _	V 3/		
	Internation interfaces for RAWAS devices Fuselage bottom side modification for RAWAS configuration	_		V V		
	Hand-operated brakes	_ √	_ √	v √		
	AUXILIARY ACCESSOR.	<u> </u>	V	V		
	Fuel Level Measuring Stick	√	√	√		
	Fuel Inspection Cup	√	√	V		
	Fuel Funnel with Filter	√	√	√		
	Yaw Gust Control Lock	√	√	√		
	2 aileron padded locks, w/ "Remove Before Flight" Streamer	√	√	√		
	Pitot tube & static port plug, w/ "Remove Before Flight" Streamer	√	√	√		
	Stall Warning port plug, w/ "Remove Before Flight" Streamer POWERPLANT	√	٧	٧		
	Engine: Rotax 912S 98hp (73,5 KW) @5.800 rpm	√	٧	V		
	Sliding clutch and improved electrical starter	√	√	√		
	2 blades fixed pitch wooden / composite propeller	√	√	√		
	Taxiing cooling fans	√	√	√		
	Adjustable cooling system for engine coolant and oil	√	√	√		
	Additional 40 Amp alternator	-	√	V		
	Vacuum Pump	√	√	√		
	Carburetor airbox	٧	√	√		
	Red painted propeller spinner	V	V	V		
	Carburetor Heating System ENGINE INSTRUMENTA:	√	V	V		
		TION				
	Tachometer Tachometer	TION √	٧	V		
			V V	٧ ٧		
	Tachometer	٧				
	Tachometer Fuel Quantity Indicator	√ √	٧	٧		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator	٧ ٧ ٧	√ √	√ √		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator	√ √ √ √	√ √ √	√ √ √		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator Oil Temperature Indicator	√ √ √ √	√ √ √	√ √ √		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator & alarm indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led	√ √ √ √ √	V V V V	√ √ √ √		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator & alarm indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led	\ \ \ \ \ \ \ \ \	V V V V V	√ √ √ √ √		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator & alarm indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp	\ \ \ \ \ \ \ \ \ \	V V V V	√ √ √ √ √ √		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp Low Oil Pressure - Red Lamp	V V V V V	V V V V V	√ √ √ √ √		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator & alarm indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp	\ \ \ \ \ \ \ \ \ \ \	V V V V V	√ √ √ √ √ √		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp Low Oil Pressure - Red Lamp High Oil Temperature - Red Lamp	\ \ \ \ \ \ \ \ \ \ \ \	V V V V V	V V V V V		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp Low Oil Pressure - Red Lamp High Oil Temperature - Red Lamp CHT - Red Lamp	\ \ \ \ \ \ \ \ \ \ \ \ \ \	V V V V V V	V V V V V V		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator Oil Pressure Indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp Low Oil Pressure - Red Lamp High Oil Temperature - Red Lamp CHT - Red Lamp Auxiliary engine and instrument panel fans ON - Blue Lamp	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	V V V V V V	V V V V V V V		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator Oil Pressure Indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp Low Oil Pressure - Red Lamp High Oil Temperature - Red Lamp CHT - Red Lamp Auxiliary engine and instrument panel fans ON - Blue Lamp Fuel Low - Amber Lamp	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	V V V V V V V	V V V V V V V		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator Oil Pressure Indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp Low Oil Pressure - Red Lamp High Oil Temperature - Red Lamp CHT - Red Lamp Auxiliary engine and instrument panel fans ON - Blue Lamp Fuel Low - Amber Lamp Voltage Regulator - Red Lamp Push to Test button (Warning Lights)	√ √ √ √ √ √ √ √ √ √	V V V V V V V V	V V V V V V V V		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp Low Oil Pressure - Red Lamp High Oil Temperature - Red Lamp CHT - Red Lamp Auxiliary engine and instrument panel fans ON - Blue Lamp Fuel Low - Amber Lamp Voltage Regulator - Red Lamp Push to Test button (Warning Lights) FLIGHT INSTRUMENTAT Magnetic Compass	√ √ √ √ √ √ √ √ √ √ √ √ √	V V V V V	V V V V V V V V		
	Tachometer Fuel Quantity Indicator Fuel Pressure Indicator & alarm indicator Oil Pressure Indicator Oil Pressure Indicator Oil Temperature Indicator Cylinder Head Temperature Indicator Vacuum gauge Volt / Ampere indicator with alarm led PILOT WARNINGS Landing light ON - blue lamp Low Oil Pressure - Red Lamp High Oil Temperature - Red Lamp CHT - Red Lamp Auxiliary engine and instrument panel fans ON - Blue Lamp Fuel Low - Amber Lamp Voltage Regulator - Red Lamp Push to Test button (Warning Lights)	√ √ √ √ √ √ √ √ √ √	V V V V V V V V	V V V V V V V V		

ľ	Altitude encoder	l v	V	√			
	Vertical Speed Indicator	V	v	V			
	Attitude Indicator (pneumatic)	, , , , , , , , , , , , , , , , , , ,	v v	√ √			
	Directional Gyro (pneumatic)	, , , , , , , , , , , , , , , , , , ,	· ·	√ √			
		V -1	· · ·	•			
	Turn and bank indicator (electric) & Sideslip Indicator	٧	V	√ .			
	Flaps position Indicator	٧	٧	V			
	Pitch Trim Position Indicator	√	V	V			
	Outside air temperature (OAT) indicator	√	V	V			
	Digital chronometer	√	√	V			
	Stall Warning System (acoustic)	√	√	V			
	Flight Hour Meter	√	√	V			
	Landing light	-	√	V			
	Navigation & strobe lights	_	V	V			
	Instrument post light w/ dimmer control	_	V	V			
	Map light	_	V	√ ·			
	AVIONICS PRE ARRANGEMENTS & WIRING						
	Vacuum subsystem w/ Suction indicator	√	V	V			
III	14 Ah power battery	√	V	V			
	COM Antenna & installation	V	V	V			
	Transponder Antenna & installation	v	V	V			
	VOR Antenna & installation	v .	7	N.			
	COM Chassis installation	, , , , , , , , , , , , , , , , , , ,	· ·	v V			
		V	-/	•			
	Transponder Chassis installation	V .	V	V			
	Breakers & Switches AVIONICS	V	V	√			
1	NAV / COM Bendix King KX-125	٧	V	_			
'	NAV / COM Bendix King KX-155 w/ CDI/VOR/GS indicator Bendix King KI-204 (replaces I)	· ·	·	_			
Ш	Bendix King KT 76A (Mode C transponder)	v/	N.	_			
	Garmin GTX 327 (Mode C transponder, replaces II)	· ·	·	1			
				-/			
	GPS/NAV/COM Garmin GNS 430 and CDI/VOR/GS indicator Garmin GI-106A (replaces I)		.,	V			
	Intercom Sigtronics SPA 400	V	٧	V			
	Headsets for two	٧	٧	V			
	Emergency Locator Transmitter	V	V	√			
	MISCELLANEOUS External power jack						
	19 Ah power battery (replaces III, upgrade)	•					
	Nose Wheel mud guard & Main Wheel fairings	•	•	•			
	Toe brakes (upgrade)	•	•	•			
IV	Rack for wing and horizontal tail transportation	•	•	•			
	Trailer for aircraft on road transportation (requires IV)	•	•	•			
	Set of stakes and ropes for aircraft tie down	•	•	•			
	Disabled pilot controls (under certification) Waterproof Front Fuselage and Canopy Cover		•				
	Waterproof Front Fuseiage and Canopy Cover Waterproof Engine Cover						
		· -	·				

Not available on the configuration
 Available as optional on the configuration
 Standard item included in the configuration